

# KEYS SEE<sup>®</sup>

## Large Print Keyboard



## User Instructions

[www.keyconnection.com](http://www.keyconnection.com)


Thank you for purchasing the Keys-U-See® Large Print Keyboard.

## SYSTEM REQUIREMENTS

- U Windows® compatible computer
- U USB (Universal Serial Bus) port connecting to your computer
- U Microsoft Windows® 7, VISTA™, XP, 2000, NT, 98, or ME

## INSTALLATION

The Keys-U-See® Large Print keyboard is designed to work automatically with most Windows® operating systems. Simply plug the USB connector cord into a USB port on your computer and you are ready to go. Some older systems such as Windows® 98 and ME will require a software driver to allow the “hot” keys to function (download available at <http://www.keyconnection.com>).



If your keyboard package includes a mouse, follow the same procedure described above to connect and use your new mouse.

## ADJUSTING THE KEYBOARD FEET

The keyboard feet underneath are designed to accommodate various body sizes, chairs, and desks. Pull out or push in the keyboard feet to a position that minimizes bending your wrists while typing.

## WHAT THE INITIALS STAND FOR













PS – Print Screen	SL – Scroll Lock	PB – Pause/Break
INS – Insert	HM – Home	PU – Page UP
DEL – Delete	PD – Page Down	NL – Number Lock

## WHAT THE KEYBOARD LIGHTS MEAN






The keyboard lights in the upper right are illuminated when the corresponding lock key is activated. For example, if NUM LOCK is on, the NUM LOCK light is on; if CAPS LOCK is on, the CAPS LOCK light is on. Press the key again to turn off.

## THE KEYBOARD HOT KEYS

The Keys-U-See® Large Print Keyboard is a full-size, 104-key model. In addition, it comes with 12 “hot” keys to enable one touch access to multimedia, internet and energy saving functions.

-  **Play/Pause:** Play or Pause audio or video file in the media player.
-  **Stop:** Stop playing the audio or video file in the media player.
-  **Mute:** Play with no sound. Press again to resume sound.
-  **Next:** Go to the next audio track or video scene.
-  **Previous:** Go to the previous audio track or video scene.
-  **- Volume Down:** Decrease the volume.
-  **+ Volume Up:** Increase the volume.
-  **Sleep:** Put computer in “sleep” mode to save energy. Press again to awaken the computer from sleep.
-  **Favorites:** Open My Favorites panel in an open navigation window. Press again to return to previous state.
-  **Search:** Open search window or search panel in an open navigation window. Press again to return to previous state.
-  **E-mail:** Launch default e-mail application.
-  **Home:** Launch default web browser (usually Internet Explorer®).

## HELPFUL TIPS

-  Windows® 7, VISTA™, or XP offer different features for users with impaired vision. For complete descriptions and step-by-step directions for making Windows® more viewable, please go to <http://www.microsoft.com/enable/aging/tips.aspx>
-  Keep all computer parts away from direct sunlight, moisture, dirt, extreme heat, and abrasive chemicals (cleaning solutions).
-  DO NOT spill or spray any liquid on the keyboard.
-  Keep your keyboard clean and free of debris such as food crumbs or dust. On a monthly basis, shake or blow out any debris and wipe with a soft damp cloth or tissue.
-  Be sure the computer is turned off before cleaning.

## TROUBLE SHOOTING

- ❏ If your keyboard is not responding, check to see that your keyboard cable is securely plugged into the correct port in the computer and your computer is plugged in and turned on. Also, check to see that there are no breaks or sharp twists in the keyboard cable.
- ❏ If your keyboard is not responding correctly, check to insure no other keyboard driver is installed in your system.

### HEALTH WARNING

Use of a keyboard or mouse may be linked to serious injuries or disorders.

When using a computer, as with many activities, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. However, if you experience symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensation, or stiffness, DO NOT IGNORE THESE WARNING SIGNS! PROMPTLY SEE A QUALIFIED HEALTH PROFESSIONAL, even if symptoms occur when you are not working at your computer. Symptoms such as these can be associated with painful and sometimes permanently disabling injuries or disorders of the nerves, muscles, tendons, or other parts of the body. These musculoskeletal disorders (MSDs) include carpal tunnel syndrome, tendonitis, tenosynovitis, and other conditions.

While researchers are not yet able to answer many questions about MSDs, there is a general agreement that many factors may be linked to their occurrence including: medical and physical conditions; stress and how one copes with it; overall health; and how a person positions and uses his or her body during work and other activities (including use of a keyboard or mouse). The amount of time a person performs an activity may also be a factor. Consult your physician for guidelines that may help you work more comfortably with your computer and possibly reduce your risk of experiencing an MSD.

If you have any questions about how your own lifestyle, activities, or medical or physical condition may be related to MSDs, see a qualified health professional.



For more information about this keyboard or any of our other Large Print Enhancement Products, please visit our website [www.keyconnection.com](http://www.keyconnection.com).